

Installation

INSTALLATION – TIPS:

The MDF panel comes pre-drilled.

You can specify to not include pre-drilling. The screws can be simply drilled through the greenery and are no longer visible after installation.

Please use the drywall anchors provided for your wall. No anchors are required for mounting on a load-bearing wooden surface.

Pole moss:

In order to prevent the seams from being visible after installation, individual mosses including glue are sent along. These are numbered, like the MDF boards, and can be fitted exactly in the appropriate places.

Reindeer moss:

The edges of the individual moss surfaces can be interlaced with the hands to conceal the transitions. Please make sure that the humidity in the room is between 40 % and max. 70 %.

Forest and pole moss / Forest moss / Plant island:

When assembling the individual panels, please ensure that the edges are close together so that a closed moss surface results.

1700 Enterprise Way
Suite 113
Atlanta, Georgia 30067

t: 470.632.0881
e. info@vibe-as.com
www.vibe-as.com

VIBF

architectural systems

