



architectural systems

broDesign Installation Instructions

1. Provide a completely dry and leveled surface for mounting.
2. If broDesign mosaics are mounted directly onto wall (without liner material such as plywood), ensure zero water seepage in the wall.
3. Applications in wet area or excessively moist areas are not advisable.
4. Any standard commercial adhesive (substrate to be considered) can be used for mounting broDesign wood mosaics. For standard installations on plywood surfaces standard PVAc white adhesives are recommended.
5. Always insist on using 1.5 mm spacers while laying out individual pieces next to each other. Standard plastic spacers of 1.5 mm can be used.
6. Always insist on applying uniform pressure on surfaces when liquid white adhesives are used and surfaces are left to cure for 6-8 hours.
7. Do not sand heavily for lacquering immediately after application.
8. If grouting material is desired, be sure the surface is dry and lacquered a minimum of one time. We do not recommend any grouting material for non-flat surfaces.
9. Epoxy grouts are highly recommended for its water resistance properties.
10. Clean the surface thoroughly with a moist cloth after filled grouting material to avoid grout remnants on the surface.
11. Standard lacquers that are used for veneered surfaces are good for mosaics as well.